



GUEST BATH & SHOWER ROOM PROTOCOL APPLICATION PROCEDURES *BioDefense 24/7*[®]

Tools:

1) Lint free application / buffing cloth 2) optional: melamine “magic eraser” sponge 3) BioDefense 24/7[®]

STEP 1: Pre-clean surfaces with approved cleaner. Rinse completely. For better results, final rinse using a water-wetted Magic Eraser sponge. This will ensure micropores are clean and ready to receive the *BioDefense 24/7*[®]. Allow your cleaned and rinsed surface to dry completely prior to STEP 2 (application).

STEP 2: Apply *BioDefense 24/7*[®] to application cloth or use mister sprayer directly on surface to be treated. This product is Nano technology...a little goes a long way! Wipe the pre-cleaned dry surface in a circular buffing motion with *BioDefense 24/7*[®]. Allow to *dry completely* prior to using the treated surface. Any left behind residue will wipe off easily.

DO NOT APPLY TO FLOORS AS THEY MAY BECOME SLIPPERY!

Re-apply every 3 to 6 months or whenever performance begins to subside

Approved for use on:

Shower walls – Sliding glass shower doors or curtains – Mirrors – Sinks – Countertops – Showerheads – Faucets - Toilets (in bowl, drain water to reach low point) – Urinals – Stainless Steel – Walls / Ceilings - Plastics

What to expect?

Shower walls and glass will shed water hardness, soap, and body oils leaving surfaces easy to clean. Mold and mildew should no longer be an issue. Reduced mirror fogging. Odors will be neutralized. Contaminates will flush easily at sinks, toilets, or urinals. Enhances countertop color and inhibits water rings & staining.